







PVC Work Stations, Pipe, Bends & Fittings

Thin Wall PVC Office Workstations & Inlets

Office Inlet Work Station	Eurovac Part No.	Description
		OFFICE INLET WORK STATION Equipment Specs: <ul style="list-style-type: none"> • 1 1/4" Inlet • Fits 1-1/4" Hose Cuff Part Numbers: <ul style="list-style-type: none"> • WS = With Switch • NS = With Switch Includes: <ul style="list-style-type: none"> • 30' of Thin Wall Pipe, Bends & Fittings • Flush Mount Inlet
	SYS-050-21114WWS	Single Flush Mount Office Work Station
Office Inlet	Eurovac Part No.	Description
		OFFICE INLET Equipment Specs: <ul style="list-style-type: none"> • 1 1/4" Inlet • Fits 1-1/4" Hose Includes: <ul style="list-style-type: none"> • Flush Mount Inlet with Switch
	SYS-050-21000000	PVC Flush Mount Office Inlet



Single Thin Wall PVC Work Station Heads (Heads Only)

Single Thin Wall PVC Wall Mnt Wk Stations - With Inlet	Eurovac Part No.	Description
		SINGLE THIN WALL MOUNT WORK STATION HEADS Equipment Specs: <ul style="list-style-type: none"> • 1 1/2" Inlet • Thin Wall PVC on 45 Elbow
	SYS-050-21500000	Single Thin Wall PVC Wall Mount Work Station Head - With Switch
	SYS-050-215N0000	Single Thin Wall PVC Wall Mount Work Station Head - With Switch
Single Thin Wall PVC Hanging Wk Stations - With Inlets	Eurovac Part No.	Description
		SINGLE THIN WALL HANGING WORK STATION HEADS Equipment Specs: <ul style="list-style-type: none"> • 1 1/2" Inlet • Thin Wall PVC
	SYS-050-22000000	Single Thin Wall PVC Hanging Work Station Head - With Switch
	SYS-050-220N0000	Single Thin Wall PVC Hanging Work Station Head - No Switch

Double Thin Wall PVC Work Station Heads (Heads Only)


Double Thin Wall PVC Wall Mnt & Hanging Wk Stations - With Inlets	Eurovac Part No.	Description
		DOUBLE THIN WALL WORK STATION HEADS Equipment Specs: <ul style="list-style-type: none"> • 1 1/2" Inlets • Thin Wall PVC
	SYS-050-225W0000	Double Thin Wall PVC Hanging / Wall Work Station Head - With Switch
	SYS-050-225N0000	Double Thin Wall PVC Hanging / Wall Work Station Head - No Switch
Double Thin Wall PVC Pendant Wk Stations - No Inlets	Eurovac Part No.	Description
		DOUBLE THIN WALL WORK PENDANT STATION HEAD Equipment Specs: <ul style="list-style-type: none"> • No Inlet Valve - Hose Cuff Connection • Thin Wall PVC
	SYS-050-2260PEND	Double PVC Pendant Work Station Head Only - No Inlet Valve

Single Heavy Wall PVC Work Station Heads (Heads Only)

Single Heavy Wall PVC Wall Mnt Wk Stations - With Inlet	Eurovac Part No.	Description
		SINGLE HEAVY WALL MOUNT WORK STATION HEADS - WITH INLET Equipment Specs: <ul style="list-style-type: none"> • 1 1/2" Inlet • Heavy Wall PVC on 45 Elbow
	SYS-050-2150H000	Single Heavy Wall PVC Wall Mount Work Station Head - With Switch
	SYS-050-215NH000	Single Heavy Wall PVC Wall Mount Work Station Head - No Switch
Single Heavy Wall PVC Wall Mnt Wk Station - No Inlet	Eurovac Part No.	Description
		SINGLE HEAVY WALL MOUNT WORK STATION HEADS - NO INLET Equipment Specs: <ul style="list-style-type: none"> • No Inlet Valve - Hose Cuff Connection • Heavy Wall PVC on 45 Elbow
	SYS-050-20600215	Single Heavy Wall PVC Wall Mount Work Station Head - No Inlet Valve




Single Heavy Wall PVC Hanging Wk Stations - With Inlet	Eurovac Part No.	Description
		SINGLE HEAVY WALL HANGING WORK STATION HEADS - WITH INLET Equipment Specs: <ul style="list-style-type: none"> • 1 1/2" Inlet • Heavy Wall PVC • Thin Wall PVC At One End - For Securing Drop Hose
	SYS-050-2200H000	Single Heavy Wall PVC Hanging Work Station Head - With Switch
	SYS-050-220NH000	Single Heavy Wall PVC Hanging Work Station Head Only - No Switch
Single PVC Hanging Wk Station - No Inlets	Eurovac Part No.	Description
		SINGLE HEAVY WALL HANGING WORK STATION HEADS - NO INLETS Equipment Specs: <ul style="list-style-type: none"> • No Inlet Valve - Hose Cuff Connection • Heavy Wall PVC - Claw Holster Mounting • Thin Wall PVC At One End - For Securing Drop Hose
	SYS-050-20600210	Single PVC Hanging Work Station Head Only - No Inlet Valve
4" Carwash Single Heavy Wall PVC Hanging Wk Stations - With Inlets	Eurovac Part No.	Description
		4" CARWASH SINGLE HEAVY WALL HANGING WORK STATION HEADS - WITH INLETS Application: <ul style="list-style-type: none"> • 4" slows material down and drops out to a bottom dump latch, reducing chance of clogs. Equipment Specs: <ul style="list-style-type: none"> • 1.8" Inlet w/ Clip • Heavy Wall PVC
	SYS-050-20514HNC	4" Carwash Single HW PVC Wk Stn Head w/ Dump Latch - 1-1/8" Inlet w/ Clip

Double Heavy Wall PVC Work Station Heads (Heads Only)

Double Heavy Wall PVC Wall Mnt Wk Stations - With Inlets	Eurovac Part No.	Description
		DOUBLE HEAVY WALL MOUNT WORK STATION HEADS - WITH INLETS Equipment Specs: <ul style="list-style-type: none"> • 1 1/2" Inlets • Heavy Wall PVC
	SYS-050-23114WWS	Double Heavy Wall PVC Wall Mount Work Station Head Only - With Switch
	SYS-050-23114WWN	Double Heavy Wall PVC Wall Mount Work Station Head Only - No Switch

Double Heavy Wall PVC Hanging Wk Stations - With Inlets	Eurovac Part No.	Description
		<p>DOUBLE HEAVY WALL HANGING WORK STATION HEADS - WITH INLETS</p> <p>Equipment Specs:</p> <ul style="list-style-type: none"> • 1 1/2" Inlets • Heavy Wall PVC • Thin Wall PVC At One End - For Securing Drop Hose
	SYS-050-23114HWS	<p>Double Heavy Wall PVC Hanging Work Station Head Only - With Switch</p>
	SYS-050-23114HWN	<p>Double Heavy Wall PVC Hanging Work Station Head Only - No Switch</p>
Double Heavy Wall PVC Wall Mnt Wk Stations - No Inlets	Eurovac Part No.	Description
		<p>DOUBLE HEAVY WALL MOUNT WORK STATION HEADS - NO INLETS</p> <p>Equipment Specs:</p> <ul style="list-style-type: none"> • No Inlet Valves - Hose Cuff Connections • Heavy Wall PVC
	SYS-050-22600000	<p>Double Heavy Wall PVC Wall Mount Work Station Head Only - No Inlet Valve</p>
Double Heavy Wall PVC Hanging Wk Stations - No Inlets	Eurovac Part No.	Description
		<p>DOUBLE HEAVY WALL HANGING WORK STATION HEADS - NO INLETS</p> <p>Equipment Specs:</p> <ul style="list-style-type: none"> • No Inlet Valves - Hose Cuff Connections • Heavy Wall PVC • Thin Wall PVC At One End - For Securing Drop Hose
	SYS-050-22600240	<p>Double PVC Hanging Work Station Head Only - No Inlet Valve</p>
4" Carwash Double Heavy Wall PVC Hanging Wk Stations - With Inlets	Eurovac Part No.	Description
		<p>4" CARWASH DOUBLE HEAVY WALL HANGING WORK STATION HEADS - WITH INLETS</p> <p>Application:</p> <ul style="list-style-type: none"> • 4" slows material down and drops out to a bottom dump latch, reducing chance of clogs. <p>Equipment Specs:</p> <ul style="list-style-type: none"> • 1.8" Inlets w/ Clips • Heavy Wall PVC
	SYS-050-23114HWC	<p>4" Carwash Double HW PVC Wk Stn Head w/ Dump Latch - 1-1/8" Inlets w/ Clip</p>

Pipe, Bends & Fittings

PVC Tubing	Eurovac Part No.	Description
		PVC TUBING Application: <ul style="list-style-type: none"> Thin wall tube/bends sometimes us on smaller EII Systems
	PPF-BEA-2PT20000	2" PVC Tubing Thin Wall - per ft. (8' lengths)
	PPF-HYT-010212WS	2" PVC Pipe Sch 40 - per ft. (10' lengths)
	PPF-HYT-010214WS	3" PVC Pipe Sch 40 - per ft. (10' lengths)
	PPF-HYT-010216WS	4" PVC Pipe Sch 40 - per ft. (10' lengths)
	PPF-HYT-010218WS	6" PVC Pipe Sch 40 - per ft. (10' lengths)
	PPF-HYT-010220WS	8" PVC Pipe Sch 40 - per ft. (10' lengths)
	PPF-HYT-010240WS	10" PVC Pipe Sch 40 - per ft. (20' lengths)
PVC Couplings	Eurovac Part No.	Description
		PVC COUPLINGS Application: <ul style="list-style-type: none"> Thin wall tube/bends sometimes us on smaller EII Systems
	PPF-PLA-SV806200	2" PVC Stop Coupler Thin Wall
	PPF-IRR-PVCCPLG2	2" PVC Slip Coupler Heavy Wall
	PPF-IRR-PVCCPLG3	3" PVC Slip Coupler Heavy Wall
	PPF-IRR-PVCCPLG4	4" PVC Slip Coupler Heavy Wall
	PPF-IRR-PVCCPLG6	6" PVC Slip Coupler Heavy Wall
	PPF-IRR-PVCCPLG8	8" PVC Slip Coupler Heavy Wall
	PPF-IRR-PVCCPLG0	10" PVC Slip Coupler Heavy Wall
90 PVC Degree Elbow	Eurovac Part No.	Description
		PVC 90 ELBOWS Application: <ul style="list-style-type: none"> Thin wall tube/bends sometimes us on smaller EII Systems
	PPF-PLA-SV804200	2" PVC Std 90 Elbow Thin Wall
	PPF-IRR-PVCLS902	2" PVC Sweep 90 Elbow Heavy Wall
	PPF-IRR-PVCLS903	3" PVC Sweep 90 Elbow Heavy Wall
	PPF-IRR-PVCLS904	4" PVC Sweep 90 Elbow Heavy Wall
	PPF-IRR-PVC00906	6" PVC Sweep 90 Elbow Heavy Wall
	PPF-IRR-PVC00908	8" PVC Sweep 90 Elbow Heavy Wall
	PPF-IRR-PVC00910	10" PVC Sweep 90 Elbow Heavy Wall

45 PVC Degree Elbow	Eurovac Part No.	Description
		PVC 45 ELBOWS Application: <ul style="list-style-type: none"> • Thin wall tube/bends sometimes us on smaller EII Systems
	PPF-PLA-SV805600	2" PVC Std 45 Elbow Thin Wall
	PPF-IRR-PVC45200	2" PVC Sweep 45 Elbow Heavy Wall
	PPF-IRR-PVC45300	3" PVC Sweep 45 Elbow Heavy Wall
	PPF-IRR-PVC45400	4" PVC Sweep 45 Elbow Heavy Wall
	PPF-IRR-PVC45600	6" PVC Sweep 45 Elbow Heavy Wall
	PPF-IRR-PVC45800	8" PVC Sweep 45 Elbow Heavy Wall
	PPF-IRR-PVC45100	10" PVC Sweep 45 Elbow Heavy Wall
Speciality PVC 45 Degree Elbow	Eurovac Part No.	Description
		PVC THIN WALL STREET 45 ELBOW Application: <ul style="list-style-type: none"> • Thin wall tube/bends sometimes us on smaller EII Systems
	PPF-PLA-SV806000	2" PVC Thin Wall Street 45 Elbow
PVC TY 90's	Eurovac Part No.	Description
		PVC TY 90's Application: <ul style="list-style-type: none"> • Thin wall tube/bends sometimes us on smaller EII Systems
	PPF-PLA-SV804800	2" PVC TY 90 Thin Wall
	PPF-IRR-PVCCY182	2" x 2" PVC TY 90 Heavy Wall
	PPF-IRR-PVCCY320	3" x 2" PVC TY 90 Heavy Wall
	PPF-IRR-PVCCY183	3" x 3" PVC TY 90 Heavy Wall
	PPF-IRR-PVCCY420	4" x 2" PVC TY 90 Heavy Wall
	PPF-IRR-PVCCY430	4" x 3" PVC TY 90 Heavy Wall
PPF-IRR-PVCCY184	4" x 4" PVC TY 90 Heavy Wall	

PVC Y 45's	Eurovac Part No.	Description
		PVC Y 45's Application: <ul style="list-style-type: none"> Thin wall tube/bends sometimes us on smaller EII Systems
	PPF-PLA-SV807200	2" PVC Y 45 Thin Wall
	PPF-IRR-PVCY2000	2" x 2" PVC Y 45 Heavy Wall
	PPF-IRR-PVCY3200	3" x 2" PVC Y 45 Heavy Wall
	PPF-IRR-PVCY3000	3" x 3" PVC Y 45 Heavy Wall
	PPF-IRR-PVCY4200	4" x 2" PVC Y 45 Heavy Wall
	PPF-IRR-PVCY4300	4" x 3" PVC Y 45 Heavy Wall
	PPF-IRR-PVCY4000	4" x 4" PVC Y 45 Heavy Wall
	PPF-IRR-PVCY6300	6" x 3" PVC Y 45 Heavy Wall
	PPF-IRR-PVCY6400	6" x 4" PVC Y 45 Heavy Wall
	PPF-IRR-PVCY8600	8" x 6" PVC Y 45 Heavy Wall
	PPF-IRR-PVCY8600	10" x 10" PVC Y 45 Heavy Wall
	PVC Double Y 45	Eurovac Part No.
		PVC THIN WALL DOUBLE Y 45 Application: <ul style="list-style-type: none"> Thin wall tube/bends sometimes us on smaller EII Systems
	PPF-PLA-SV807000	2" PVC Thin Wall Double Y 45
PVC Double Y 90	Eurovac Part No.	Description
		PVC HEAVY WALL DOUBLE Y 90's
	PPF-IRR-PVCDTY20	2"x 2"x 2" PVC Heavy Wall Double 90 Y
	PPF-IRR-PVCDY200	2"x 2"x 2"x 2" PVC Heavy Wall Double TY 90
PVC Tees	Eurovac Part No.	Description
		PVC STRAIGHT TEE Application: <ul style="list-style-type: none"> Typically used for hiding brass fittings for chem lines. Tees are cut in half, placed over chem fittings/lines and secured with cable ties.
	PPF-PSP-0T020020	2" x 2" PVC SCH 40 Straight Tee White
	PPF-PSP-0T040040	4" x 4" PVC SCH 40 Straight Tee White
PVC Bushings	Eurovac Part No.	Description
		PVC HEAVY WALL BUSHINGS
	PPF-IRR-PVCBU320	3" x 2" PVC Bushing Heavy Wall
	PPF-IRR-PVCBU430	4" x 3" PVC Bushing Heavy Wall
	PPF-IRR-PVCBU640	6" x 4" PVC Bushing Heavy Wall
	PPF-IRR-PVCBU860	8" x 6" PVC Bushing Heavy Wall

PVC Heavy Wall To Thin Wall	Eurovac Part No.	Description
		PVC HEAVY WALL TO BUSHINGS
	PPF-PAB-20HW20TW	2" PVC HW Socket To 2" PVC Adaptor
	PPF-BEA-2PTN0600	2" x 6"L PVC TW Tube Nipple
PVC End Cap	Eurovac Part No.	Description
		PVC END CAPS Application: • Thin wall tube/bends sometimes us on smaller EII Systems
	PPF-PLA-SV808000	2" PVC End Cap Thin Wall
	PPF-IRR-PVCCO200	2" PVC Cleanout w/ Plug Heavy Wall
	PPF-IRR-PVCCO300	3" PVC Cleanout w/ Plug Heavy Wall
Pipe Hangers	Eurovac Part No.	Description
		PIPE HANGERS Equipment Specs: • 7/16" Mounting Hole Includes: • Screw & Nut
	HAR-TOR-05HANGER	2" PVC Hanger
	HAR-TOR-07HANGER	3" PVC Hanger
	HAR-TOR-09HANGER	4" PVC Hanger
Pipe Hangers (Swivel)	Eurovac Part No.	Description
		PIPE HANGERS (SWIVEL TYPE)
	HAR-GRI-30184100	6" Pipe Hanger (Swivel Type)
	HAR-GRI-30188200	8" Pipe Hanger (Swivel Type)
PVC Glue	Eurovac Part No.	Description
		PVC GLUE
	PPF-PLA-SC025000	PVC Glue 250ml
	PPF-IRR-PVCCE1PT	PVC Glue 1 PT (568ml)